

MG

A white horizontal line spans the width of the image, ending with a pulse icon consisting of a small triangle pointing up, followed by a small circle with a dot in the center.

# Index

- Master LV product features
- BMS
- Diagnostic tool
- Troubleshooting
- Digital control of Victron chargers/inverters (DVCC)
- Commissioning

# Master

# LV



# Available Models

**12 Vdc**

400A

600A

1000A

**24-48 Vdc**

400A

600A

1000A

**72-96 Vdc**

500A

# Master LV


- Cell balancing (BMS)
- Safety contactor
- Pre-charge
- Shunt
- DC distribution
- Fuse box
- Bluetooth



# Safety and control unit

Protection against:

- Over-charging
- Over-discharging
- Over-temperature
- Under-temperature
- Balancing



# Balancing (BMS)

## Main function: battery bank protection

Gathering cell voltage and temperatures from the battery modules


Monitors cell voltage, temperatures and current

Monitors communication time-out on the batteries


Controls balancing

Event logging to internal flash memory

Charger/loads control



# Safety Contactor






# Safety Contactor

Integrated safety contactor as second level protection

Models:

- 150A / 400A / 600A / 1000A  
(12 and 24 / 48 Vdc)
- 500A  
(72 Vdc and 96 Vdc)




# Pre-Charge


Automatic at startup

Safety contactor closes when 80% of the battery voltage is reached

- No welding of the safety contactor
- No sparks




# DC Distribution



**Battery**  
connections


**Chargers & load**  
connections

# DC Distribution



# DC Distribution

- Bolt down M8
- 4 inputs and 4 outputs available
- Fuse holder (+) MEGA Fuse
- Max. cable diameter: 120 mm<sup>2</sup> (depending on cable lug)




# Fuses

**Fuse** main  
control unit (PCB)

Pre-charge  
**fuse** (10A)

**Fuse** holders  
to protect  
parallel battery banks  
(4x)

**Fuse** holders  
to protect  
chargers and loads  
(4x)



# Shunt



# CAN-Bus



## CAN-Bus communication

- NMEA2000
- SMA
- Custom



# I/O Connections




To control chargers and loads  
(allow to charge / allow to discharge)

Programmable contact

Remote on/off switch and status LED

# I/O Connections



Connector pins and specifications					
Conn.	Pin	I/O	Voltage	Current	Purpose
A	1	Out	13,5 V	1 A	Aux. power output
	2	Out	13,5 V	1 A	Allow-to-Charge
	3	Out	13,5 V	1 A	Allow-to-Discharge
	4	In			External start button
	5	Out	13,5 V	140 mA	External status output
	6	-			GND
B	1	Out	Max. 60 VDC	0,8 A @ 60 VDC	Allow-to-charge
	2				
	3	Out	Max. 60 VDC	0,8 A @ 60 VDC	Allow-to-discharge
	4				
	5	Out	Max. 60 VDC	0,8 A @ 60 VDC	Programmable output
	6				

# Aux Power Output



## Connector A

**Pin 1** Aux. power output (13.5 V - 1 A)

**Pin 6** GND

Connect Pin 1 and 6 to a Victron GX device to enable remote updating by VRM

Victron GX device  
CCGX  
Cerbo GX  
Octo GX





# Aux Power Output




Aux. power output is non-isolated

Aux. GND (ground) is battery ground

Victron GX device  
CCGX  
Cerbo GX  
Octo GX



# External Start Button & Status Indication




## Connector A

Pin 4: External Start button

Pin 5: External Status output

Pin 6: GND


# External Start Button & Status Indication



Start button must be momentary  
Status LED must be 12V type

# External Start Button & Status Indication

- Start button must be momentary
- Status LED must be 12V type






# Programmable Relay

Switching possible on the following parameters:


- State-Of-Charge
- Current
- Temperature
- Cell voltage
- Failsafe
- Warning
- System Active
- Discharge almost not allowed

# Programmable Relay




Connector pins and specifications					
Conn.	Pin	I/O	Voltage	Current	Purpose
A	1	Out	13,5 V	1 A	Aux. power output
	2	Out	13,5 V	1 A	Allow-to-Charge
	3	Out	13,5 V	1 A	Allow-to-Discharge
	4	In			External start button
	5	Out	13,5 V	140 mA	External status output
	6	-			GND
B	1	Out	Max. 60 VDC	0,8 A @ 60 VDC	Allow-to-charge
	2				
	3	Out	Max. 60 VDC	0,8 A @ 60 VDC	Allow-to-discharge
	4				
	5	Out	Max. 60 VDC	0,8 A @ 60 VDC	Programmable output
	6				

# Programmable Relay



Connector pins and specifications					
Conn.	Pin	I/O	Voltage	Current	Purpose
A	1	Out	13,5 V	1 A	Aux. power output
	2	Out	13,5 V	1 A	Allow-to-Charge
	3	Out	13,5 V	1 A	Allow-to-Discharge
	4	In			External start button
	5	Out	13,5 V	140 mA	External status output
	6	-			GND
B	1	Out	Max. 60 VDC	0,8 A @ 60 VDC	Allow-to-charge
	2				
	3	Out	Max. 60 VDC	0,8 A @ 60 VDC	Allow-to-discharge
	4				
	5	Out	Max. 60 VDC	0,8 A @ 60 VDC	Programmable output
	6				


# M12 CAN-Bus




M12  
Terminator  
(male)

RJ45  
Terminator

M12  
Terminator  
(male)



# Master LV: BMS State Machine



# Power-up Sequence

1. Make sure that all energy consumers are switched off before starting up the system, because the MG Master LV will pre-charge the system before closing the safety contactor.
2. Press the START-button (green button) on the front of the MG Master LV to start the system.
3. The system is pre-charging now. The safety contactor is closed as soon as the voltage rises above 80% of the battery voltage.
4. If the status LED is continuously on, the system is running and ready for use.


**NOTE: Pre-charge can handle a max. of 10A.  
Make sure DC-users are off during pre-charging.**

# Pre-Charging

- Before closing the main safety contactor, the output of the MG Master LV will be pre-charged by a relay and resistor.
- Pre-charge circuit can handle up to 10A of constant DC-consumers.
- The main contactor closes if the output voltage is more than 80% of the system battery voltage within 10 seconds (in future firmware it will be 30 seconds). If this condition is not reached within the specified time the MG Master LV will go to failsafe (error 5).
- Error 6 will occur when pre-charge fuse is broken.



# USB CAN-Interface



# Diagnostic Tool

Tool to read status on pack and battery level, shows event list, history values and used to do settings.


Connect a laptop or PC with windows with an USB-CAN interface to the BMS CAN-Bus of the Master LV.

Supported USB-CAN interfaces: **MG USB-CAN, Kvaser, PCAN (Victron)**

Old tool versions don't work with new firmware versions. For example Diagnostic tool 2.08 works only with firmware 1.8. If firmware is update to 1.10, Diagnostic tool 2.10 needs to be used.


# Diagnostic Tool

- Overview status
- Event logging
- Tracking values (history)
- Settings
- Programmable relay
- Emergency button
- Updating firmware





MG DIAGNOSTIC TOOL 2.29



## Status Events Tracking Settings Spectators

Battery strategy	Performance ▾	External CAN bus Powerfinn chargers	Disabled ▾
External CAN bus protocol	MG NMEA2000 ▾	Combined battery mode	Enable ▾
External CAN bus SOC Sync group	1 ▾		
LV Interlock/Emergency enabled	No ▾		
Invert charge allowed relay	No ▾		
Invert charge allowed signal	No ▾	Bluetooth	Enable ▾
Invert discharge allowed relay	No ▾	Charge current limit	25 A + -
Invert discharge allowed signal	No ▾	Discharge current limit	150 A + -
Number of batteries in series	0 + -	System voltage calibration offset	0.0000 + -
Number of batteries in parallel	0 + -	System voltage calibration multiplier	1.0000 + -
Start up when charger is detected	Yes ▾	I/O voltage calibration offset	0.0000 + -
Auto-shutdown condition	Almost discharged ▾	I/O voltage calibration multiplier	1.0000 + -
Auto-shutdown idle threshold	1.00 % + -	Current calibration offset	-30.0000 + -
Auto-shutdown idle time	25 minutes + -	Current calibration multiplier	1.0177 + -
Programmable relay behavior	CONFIGURE...		
		APPLY	CHECK MASTER TIME: ?

Master LV 24-48V 150A V1.1 (firmware 1.29) (Unique Identifier: 20330000)

Startup when  
charger detected



# Troubleshooting

---


When the Master LV is in failsafe mode, the status LED will blink and there will be a beep. This is in sync. The number of beeps is the failsafe error number.

Typical errors (failsafe = main contactor open):

- Battery communication error (2): BMS-CAN cables not connected right or broken.
- Under and overvoltage (3): allow-to-charge and allow-to-discharge not connected or do not function.  
Test this separately.
- Under and over temperature (4): check battery temperatures and allow-to-charge / allow-to-discharge.
- Pre-charge error (5 & 6): Pre-charge time-out or Pre-charge fuse broken because of high DC-users at the output.

# Digital Control of Victron Chargers/Inverters (DVCC)

- No allow-to-charge and allow-to-discharge contacts anymore
- No configuration of Multi/Quattro's/MPPT's
- Easier installation (plug-and-play)



# Digital Control of Victron Chargers/Inverters (DVCC)

1. Update all Quattro's/Multi's/Solar MPPT's/Lynx BMS/CCGX to the latest firmware.

Minimum firmware version needed:

Multi/Quattro: 422

CCGX / Venus GX: v2.12

VE.Direct MPPTs: v1.29

VE.Can MPPT Solar Chargers cannot be used: they do not yet support the new control mechanisms.

Lynx Ion + Shunt: v2.04

Lynx BMS: v1.09


**NOTE:** All components must be digitally connected to the CCGX.

Meaning that:

- Solar MPPT's needs to be connected with VE.Direct
- Quattro's/Multi's needs to be connected with VE.Bus
- Lynx ion BMS needs to be connected with VE.CAN

# Digital Control of Victron Chargers/Inverters (DVCC)

2. Set the DVCC setting to ON in the CCGX.
  - a. Menu -> Settings -> System setup -> Battery monitor: set to Lynx BMS
  - b. Menu -> Settings -> System setup -> DVCC: set to ON
3. Check if BMS control status is going to ON.





# Commissioning

Steps during commissioning:

1. Check connections (power and signal).
2. Check if firmware is up to date of all equipment.
3. Set Master LV configuration (optional, but recommended)
  - a. Set a fixed battery configuration
  - b. Set default or performance mode
4. If using DVCC with a CCGX then check if settings are right and BMS control status is "on".
5. Check functionality of programmable contact (if used).
6. Charge the batteries until synchronized (100%).